

LOITOR Visual-Inertial Camera


Instruction manual V0.6

Loitor Visual Inertial Camera is a general vision sensor designed for visual algorithm developers. Providing abundant hardware control interface and data interface aimed to reduce development threshold with reliable image and inertial data.


## 1. Hardware Specifications

---

### 1.1 Physical Dimensions



### 1.2 Camera Coordinate System between Left camera and IMU




### 1.3 Hardware Performance and Specifications

	CMOS	IMU
Type	MT9V034	MPV-6050
Exposure Mode	Global shutter	–
Controller IC	CY68013	STM-32
FPS	24-65fps	200fps
Supported Resolution	320*240/640*480/752*480	–
Firmware Update	Firmware Update Supported By Windows Software	–
Baseline	10cm	–
Lens physical interface	M12 Lens interface	–
Lens Specifications	2.1mm/150°+6mm/60°	–
Data interface	Usb 2.0	
Data Delay	(1/Current_FPS)s	100us
Frame Synchronization	Stereo Synchronization Triggered By Camera Driver	–

## 2. Product Feature

---

2.1 IMU zero bias calibration program, Zero bias initialization algorithm of DMP, High precision 6-DOF data, Minimum attitude drift.



## 2.2 Stereo optical parameters already accurately calibrated



2.3 The lens seat rifled through special processing, to ensure the camera would not loosen in the long-term delivery and the lens can be replaced.



2.4 SDK needs no compilation, no special dependency libraries (only rely on libusb)


2.5 stable and reliable ROS driver

2.6 Ubuntu 16/14 supported


### 3. Hardware&Software Architecture

---

#### 3.1 Hardware Architecture



#### 3.2 SDK Architecture



#### 4. SDK directory structure and Demo compilation step by step

##### 4.1 SDK directory structure

```

root@ditech-XPS-13-9343:~/workspace/Loitor_VI_Sensor_SDK_V1.1# tree
.
├── imu calib
│   ├── inucal -----> IMU Calibration Program
│   └── inucaldata.txt -----> IMU Calibration Result
├── ROS
│   └── loitor_stereo_visensor -----> Ros Package
│       ├── CMakeLists.txt
│       ├── CMakeLists.txt~
│       └── include
│           ├── loitor_stereo_visensor
│           │   ├── loitorimu.h
│           │   ├── loitorusbcam.h
│           │   └── loitorusbcam.h~
│           ├── libloitorimu.a
│           ├── libloitorusbcam.a
│           ├── Loitor_VISensor_Setups.txt
│           ├── package.xml
│           └── src
│               ├── loitor_stereo_visensor.cpp
│               └── loitor_stereo_visensor.cpp~
└── SDK -----> C++ SDK catalog
    ├── CMakeLists.txt
    ├── Loitor_VISensor_Setups.txt
    └── src
        ├── camtest2.cpp -----> C++ sample program
        ├── camtest2.cpp~
        ├── libloitorimu.a -----> Loitor SDK Static Library
        ├── libloitorusbcam.a
        ├── loitorimu.h -----> Loitor Header File
        └── loitorusbcam.h

```

9 directories, 23 files

```

root@ditech-XPS-13-9343:~/workspace/Loitor_VI_Sensor_SDK_V1.1#

```

## 4.2 C++ sample program compilation

This program is the minimum demonstration of Loitor SDK, please make sure OPENCV has been successfully installed on your computer.

If not installed, the latest version of OPENCV can be downloaded in official website.

1. choose your work space, such as /home/workspace/
2. Copy /Loitor\_VI\_Sensor\_SDK\_V1.1/SDK to /home/workspace/
3. start command line, enter the ROOT

```
cudo -s
```

4. Enter SDK catalog

```
cd/home/workspace/Loitor_VI_Sensor_SDK_V1.1/SDK
```

5. Execute CMake

```
cmake .
```


## 6. Compile the sample program

`make`

## 7. Execute Demo program

`./camtest2`

## 8. Applications results



## 9. If program failed, please see 11.1 for solution.

## 4. 3 ROS Package

~~ROS Package~~ this Package rely on

`cv_bridge`

`image_transport`

`opencv2`

`roscpp`

`rospy`

`sensor_msgs`

`std_msgs`

## 1. find your catkin workspace and enter /src catalog

`cd/home/workspace/catkin_ws/src`

## 2. Copy /Loitor\_VI\_Sensor\_SDK\_V1.1/ROS/loitor\_stereo\_visensor to catkin\_ws/src

## 3. Enter catkin workspace



```
cd/home/workspace/catkin_ws
```

#### 4. Compile

```
catkin_make
```

5. If compilation successful, the ROS Node can run normally; Otherwise you need to check whether Loitor ROS Package has been successfully installed in ROS system.

#### 4.4 ROS Package:How to start

1.Before running, update the ROS environment variables

```
Source/devel/setup.bash
```

2.Once step 4.3 is successful, you can start the ROS node, the command is:


```
Rosrun loitor_stereo_visensor loitor_stereo_visensor  
SETTINGS_FILE_PATH
```

You need replace SETTINGS\_FILE\_PATH with the actual path

of “Loitor\_VISensor\_Setups.txt” , such as:

```
/home/di-tech/workspace/Loitor_VI_Sensor_SDK_V1.1/SDK/Loitor_VISensor  
_Setups.txt
```

3. expected output:

A terminal window with a dark background and light-colored text. The window title is 'root@diTech-XP5-13-9343: ~/workspace/catkin\_ws'. The output shows a series of lines where a topic 'visensor\_imudata\_pack' is being subscribed to, followed by three numerical values separated by commas. The values vary slightly between lines, representing sensor data over time.

```
root@diTech-XP5-13-9343: ~/workspace/catkin_ws  
visensor_imudata_pack->a : 9.39686 , 0.501757 , 2.54231  
visensor_imudata_pack->a : 9.38129 , 0.467029 , 2.63093  
visensor_imudata_pack->a : 9.3777 , 0.475411 , 2.59021  
visensor_imudata_pack->a : 9.3789 , 0.493374 , 2.5495  
visensor_imudata_pack->a : 9.36213 , 0.481399 , 2.56866  
visensor_imudata_pack->a : 9.36692 , 0.534089 , 2.5974  
visensor_imudata_pack->a : 9.35375 , 0.468226 , 2.62734  
visensor_imudata_pack->a : 9.39327 , 0.520917 , 2.5507  
visensor_imudata_pack->a : 9.35734 , 0.494572 , 2.63213  
visensor_imudata_pack->a : 9.36692 , 0.518522 , 2.55429  
visensor_imudata_pack->a : 9.39087 , 0.516127 , 2.67763  
visensor_imudata_pack->a : 9.33938 , 0.492177 , 2.60937  
visensor_imudata_pack->a : 9.38488 , 0.483794 , 2.5974  
visensor_imudata_pack->a : 9.36453 , 0.482596 , 2.61297  
visensor_imudata_pack->a : 9.38848 , 0.486189 , 2.51118  
visensor_imudata_pack->a : 9.36093 , 0.461041 , 2.63811  
visensor_imudata_pack->a : 9.3777 , 0.507744 , 2.58063  
visensor_imudata_pack->a : 9.36692 , 0.504152 , 2.58303  
visensor_imudata_pack->a : 9.35974 , 0.499362 , 2.61416  
visensor_imudata_pack->a : 9.3765 , 0.492177 , 2.55668  
visensor_imudata_pack->a : 9.38129 , 0.499362 , 2.58542  
visensor_imudata_pack->a : 9.35135 , 0.467029 , 2.61416  
visensor_imudata_pack->a : 9.35614 , 0.500559 , 2.56267
```

4. If your ROS operation permission is not the root but the average user, it may lead to the problem that ROS driver quit automatically. You can solve the problem following 11.1.

#### 4.5 Get the Timestamp Data


Image data and IMU data have been added precise timestamp by Loitor ROS Drive, you can get them in msg.header.Stamp.

### 5. Camera Configuration File

If you look at the usage of main() in camtest2.CPP file, you will find the use of SDK is very simple:

- 1.visensor\_load\_settings( "Loitor\_VISensor\_Setups.txt" );//Load the camera configuration file
- 2.Visensor\_Start\_Cameras();//Start the camera
- 3.Visensor\_Start\_IMU();//Start IMU

first, we require the system load the camera configuration file, since the file contains several parameters for camera and IMU.Follow the picture:



Blue area is used to record imu zero bias, and specific set method will be given in step 8.

## 6. visensor API Instructions

---

### 6.1 Camera Controls

1. void visensor\_set\_auto\_EG(int E\_AG);

Set the exposure mode:

E\_AG=0 means manual mode, you need to set the exposure value manually;

E\_AG=1 means automatic mode (Limit of 0-255);

E\_AG=2 means automatic&manual mode(setting the gain value):

visensor\_set\_gain()

E\_AG=3 means automatic gain&exposure mode

2. void visensor\_set\_exposure(int\_man\_exp);

Set manual exposure value (Limit of 0-255)

3. void visensor\_set\_gain(int\_man\_gain);

Set the manual gain value

4. void visensor\_set\_max\_autoExp(int max\_exp);

Set maximum on automatic exposure mode (limit of 0-255)

5. void visensor\_set\_max\_autoEXP(int max\_exp);

Set minimum of automatic exposure mode (limit of 0-255)

6. void visensor\_set\_resolution(bool set\_wvga);

Set the resolution, set\_wvga=true means 752\*480 otherwise 640\*480;

7. void visensor\_set\_fps\_mode(bool fps\_mode);

Set the frame rate:

Fps\_mode=true means High frame rate:

According to HB under WVGA, range from 40fps-50fps;

According to HB under VGA, range from 50fps-65fps;

Fps\_mode=false means Low frame rate:

According to HB under WVGA, range from 22fps-27fps;

According to HB under VGA, range from 22fps-25fps;

8. void visensor\_set\_current\_HB(int HB);

Set current HB .range from 70-255;

9. void visensor\_set\_desired\_bin(int db);

Set up automatic exposure to "Achieve brightness", CMOS will adjust exposure automatically according to the numerical. The higher the db, the brighter the image ranging from 0 to 48.

10. void visensor\_set\_cam\_selection\_mode(int\_visensor\_cam\_selection);

You can choose different mode of "left eye", "right eye" and "binocular" through Camera.

\_visensor\_cam\_selection=0 means "binocular";

\_visensor\_cam\_selection=1 means "right eye";

\_visensor\_cam\_selection=2 means "left eye";

11. void visensor\_set\_current\_mode(int\_mode);

Change the current camera work mode manually.

12. int visensor\_Start\_Cameras(); | void visensor\_Close\_Cameras();

Start and turn off the camera safely.

Function Visensor\_Start\_Cameras() should be called after calling function 1-11 which means if you need to change the camera settings through API it should be acted before visensor\_Start\_Cameras.

13. void visensor\_save\_current\_settings();

To save the current mode settings in the configuration file should be acted after function 1-11.

## 6.2 Image data read interface

1. void visensor\_get\_stereolmg(char\*left\_img, char\*right\_img);

Fetch current left-eye&right-eye images(single channel)

2. void

visensor\_get\_stereolmg(char\*left\_img, char\*right\_img, timeval&left\_stamp, timeval\*right\_stamp);

Fetch current left-eye&right-eye images(single channel) and return the timestamp of shooting time.

3. visensor\_get\_leftlmg(char\*left\_img);

Only fetch the left-eye image.

4. void visensor\_get\_leftlmg(char\*left\_img, timeval\*left\_stamp);

Only fetch the left-eye image and return the timestamp of shooting time.

```
5.visensor_get_rightImg(char*right_img);
```

Only fetch the right-eye image.

```
6.void visensor_get_rightImg(char*right_img,timeval*right_stamp);
```

Only fetch the right-eye image and return the timestamp of shooting time.

### 6.3 IMU Control

```
1.visensor_Start_IMU();
```

Open the serial port and start IMU.

```
2.void visensor_Close_IMU();
```

Turn off IMU safely.

```
3.void visensor_set_imu_portname(char*input_name);
```

Set the serial port name manually.

### 6.4 IMU Data

```
1.void visensor_set_imu_bias(float bx,float by,float bz);
```

Setting IMU zero bias manually.

```
2.visensor_imudata visensor_imudata_pack
```

The variables are set as global variables to record current IMU data(timestamp included) and it can be referenced as loitorimu.h

## 7. Setting HB parameters manually

HB (Horizontal Blanking) line of Blanking, a CMOS MT9V034 register which is an important parameter, it can affect the size of the frame rate, if the setting is not appropriate (too big or too small) also can result in images caton, frame lost even USB connection failure.

The greater the HB, each frame transmission time is longer, the lower frame rate; If your USB bus capacity is limited, we suggest set the HB to around 250.

HB is smaller, the higher acquisition frame rate, but the greater the pressure for USB transmission. Smaller HB values (such as 120–194) is more suitable for PC with strong USB transmission ability.

If you find the camera there lost frames and caton, modify HB values

through the API, and then call `visensor_save_current_settings()` to save the Settings.


#### 8. IMU accelerometer zero calibration procedure

1. Follow the command line to enter IMU\_Calib folder, start  
. / imucalib to set zero calibration according to clew .
2. After calibration completed it will automatically write into the configuration file: imucaldata. TXT , then you need to manually copy the three parameters in the configuration file to Loitor\_VISensor\_Setups. TXT in the blue area.

#### 9. Optical calibration

We use the ROS camera\_calibration factory for camera calibration, its parameters has been written to the file:

/ ORB\_SLAM2 / Examples/Stereo/EuRoC.yaml



#### 10. Compile the ORB - SLAM2 and use Loitor camera for testing

1. Following the ORB - SLAM2 official guidance for ORB - SLAM2 compilation and configuration.
2. Since the optical calibration has been completed, first run Loitor ROS Node after compilation, then run the ORB - SLAM2 following default

configuration.

## 11. Several Problems you may meet

---

### 11.1 serial file cannot be opened

1. The serial port name is wrong; You need to check the USB device serial path, and write the paths in the corresponding part in

Loitor\_VISensor\_Setups. TXT

2. Ordinary users can't open the serial port under file (access problem) :  
Under Linux device you need to use sudo or the root user and in order to make ordinary users also can use a serial port you can increase the udev rules to implement, the specific method is as follows:

Sudo vim/etc/udev/rules. D / 70 - ttyusb. Rules

Add the following contents:

KERNEL == "ttyUSB [0-9] \*", the MODE = "0666", save and insert the USB to turn over serial port, it can be solved.

11.2 When IMU is on electricity you need to wait for 8 to 10 seconds and initialize the gyroscope to zero bias, remain the camera still, otherwise will result in attitude drift obviously.

For more information please visit  
<https://github.com/loitor-vis>